# Mini-Scout-Mount-700<sup>TM</sup> Installation Instructions

For Remingon® Model 700 Rifles with STANDARD contour barrels.

## STEP #1. \*\*\*\*BE POSITIVE THAT YOUR RIFLE IS NOT LOADED!!!!\*\*\*\*

- 1. Treat ALL guns as if they are LOADED.
- 2. NEVER let the muzzle point at anything you are not willing to <u>destroy</u>.
- 3. Keep you finger OFF the trigger.
- 4. REMOVE the MAGAZINE.
- 5. OPEN THE BOLT and CHECK the CHAMBER.
- 6. CLOSE the BOLT, then OPEN it AGAIN and RECHECK the CHAMBER.

### STEP #2 REMOVE THE REAR SIGHT.

- START with the rifle on a flat and sturdy table or bench surface.
- Loosen the screw on the side of the <u>rear sight slide</u>.
- Move the rear sight slide down (to the rear) until both of the screws in the sight ramp are exposed.
- Remove the two screws from the rear sight ramp and set the rear sight assembly aside.

#### STEP#3 REMOVE THE STOCK

- Remove the barrel-receiver from the stock and set aside.
- If you don't know how to remove the stock, consult the firearm owner's manual.

#### STEP #4 POSITION THE MOUNT BODY

- Place the *Mount Body* on top of the barrel.
- Position the *Mount Body* so its rear end is almost touching the front of the receiver.
- Look down through the two holes in the top of the *Mount Body* and slide it forward or backward until it lines up with the rear sight ramp screws on the barrel.
- Insert the 6-48x3/8 socket head screws (provided) into the holes and secure with the 5/64<sup>th</sup> hex key (provided).

#### STEP #4 SECURING THE BARREL CLAMP

- Turn the rifle upside down with the *Mount Body* resting on the table or workbench.
- Place the *Barrel Clamp* over the rifle barrel with holes in the flanges lined up with the threaded holes in the *Mount Body*.
- Insert the flanges of the *Barrel Clamp* into the corresponding recesses in the *Mount Body*.
- You may need to tap the barrel clamp <u>lightly</u> with a <u>soft</u> punch to get the clamp seated onto the barrel and into the recess of the mount body.
- Start the socket-head cap screws provided through the *Barrel Clamp* and into the *Mount Body*. We recommend using some type of medium thread locker on the screws.
- Tighten the screws evenly with the hex wrench provided so they are snug.





#### STEP #5 RE-ASSEMBLE THE RIFLE

- Replace the stock.
- Work the bolt assembly and check for any binding or contact that interferes with proper operation.
- The *Mini-Scout-Mount*<sup>TM</sup> does not impede the operation of the rifle in any way.



#### TIPS & TROUBLE SHOOTING

- Red-dot sights, scout scopes, or pistol scopes can be mounted anywhere along the Picatinny rail to suit the shooter's preference.
- Our *Tactical Light Mount Kit* provides a convenient mounting surface for tactical flashlights, IR illuminators, and even an additional laser sight or holo-sight. Larger flashlights can be mounted with quick-detachable scope rings. There are two different styles of *Tactical Light Mount Kit* to choose from.
- Our *Detachable Sling Mount Kit* provides a convenient and sturdy attachment point for detachable sling swivels and will fit any of our mounts.
- If you have any problems with the fit or function, break or lose a part, just call or email us.

Check out our other fine products on our website at www.amegamounts.com.

MEGA RANGES, INC. 6355 Stinson Street #202 Plano, TX 75093



